

## TB74 Protocol for RS232 106U / Pulse

**VND9 Support bill 1K 、 2K 、 5K 、 10K 、 20K 、 50K 、 100K 、 200K 、 500K (VietNam)**

### DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / VND 1000	OFF	OFF	OFF							
	2 Pulse / VND 1000	OFF	OFF	ON							
	3 Pulse / VND 1000	OFF	ON	OFF							
	4 Pulse / VND 1000	OFF	ON	ON							
	5 Pulse / VND 1000	ON	OFF	OFF							
	10 Pulse / VND 1000	ON	OFF	ON							
	20 Pulse / VND 1000	ON	ON	OFF							
	100 Pulse / VND 1000	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept VND 1000 & 2000						ON				
	Reject VND 1000 & 2000						OFF				
★	Accept VND 5000 & 10000							ON			
	Reject VND 5000 & 10000							OFF			
★	Accept VND 20000 & 50000								ON		
	Reject VND 20000 & 50000								OFF		
★	Accept VND 100000 & 200000									ON	
	Reject VND 100000 & 200000									OFF	
★	Accept VND 500000										ON
	Reject VND 500000										OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

### DIP SW SETTING : 2

FUNCTION		SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol		ON		
	RS232 Protocol		OFF		
	Reserved			ON	
★	Reserved			OFF	
	Reserved				ON
★	Reserved				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch