

TB74 Protocol for RS232 004 / Pulse

ARS9 Support bill 2 、 5 、 10 、 20 、 50 、 100 、 200 、 500 、 1K(Argentina)

DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / ARS 1	OFF	OFF	OFF							
	2 Pulse / ARS 1	OFF	OFF	ON							
	3 Pulse / ARS 1	OFF	ON	OFF							
	4 Pulse / ARS 1	OFF	ON	ON							
	5 Pulse / ARS 1	ON	OFF	OFF							
	10 Pulse / ARS 1	ON	OFF	ON							
	20 Pulse / ARS 1	ON	ON	OFF							
	100 Pulse / ARS 1	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low					ON					
★	Inhibit level Active High					OFF					
★	Accept ARS 2 & 5						ON				
	Reject ARS 2 & 5						OFF				
★	Accept ARS 10 & 20							ON			
	Reject ARS 10 & 20							OFF			
★	Accept ARS 50 & 100								ON		
	Reject ARS 50 & 100								OFF		
★	Accept ARS 200 & 500									ON	
	Reject ARS 200 & 500									OFF	
★	Accept ARS 1000										ON
	Reject ARS 1000										OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

DIP SW SETTING : 2

FUNCTION		SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol		ON		
	RS232 Protocol		OFF		
	Reserved			ON	
★	Reserved			OFF	
	Reserved				ON
★	Reserved				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch