



TP70P3B/P5 Protocol for RS232 104U / Pulse

AED6 Support bill 5 、 10 、 20 、 50 、 100 、 200 (United Arab Emirates)

DIP SW SETTING : 1

FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / AED 5	OFF	OFF	OFF							
	2 Pulse / AED 5	OFF	OFF	ON							
	3 Pulse / AED 5	OFF	ON	OFF							
	4 Pulse / AED 5	OFF	ON	ON							
	5 Pulse / AED 5	ON	OFF	OFF							
	10 Pulse / AED 5	ON	OFF	ON							
	20 Pulse / AED 5	ON	ON	OFF							
	100 Pulse / AED 5	ON	ON	ON							
	Fast Output Pulse	Lo=50ms Hi=100ms			ON						
★	Slow Output Pulse	Lo=50ms Hi=300ms			OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept AED 5						ON				
	Reject AED 5						OFF				
★	Accept AED 10							ON			
	Reject AED 10							OFF			
★	Accept AED 20								ON		
	Reject AED 20								OFF		
★	Accept AED 50									ON	
	Reject AED 50									OFF	
★	Accept AED 100 & 200										ON
	Reject AED 100 & 200										OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

DIP SW SETTING : 2

FUNCTION		SW1	SW2	SW3	SW4
★	Pulse Normal High (NO)	ON			
	Pulse Normal Low (NC)	OFF			
★	Pulse Protocol		ON		
	RS232 Protocol		OFF		
	Straight			ON	
★	Turn Over			OFF	
	Reserved				ON
★	Reserved				OFF

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch