



TP70P3B/P5 Protocol for RS232 104U / Pulse

PEI5 Support bill 10、20、50、100、200 (Peru)

DIP SW SETTING : 1

| FUNCTION | | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|----------|---------------------------|---------------------|-----|-----|-----|-----|-----|-----|-----|-----|------|
| ★ | 1 Pulse / PEI 10 | OFF | OFF | OFF | | | | | | | |
| | 2 Pulse / PEI 10 | OFF | OFF | ON | | | | | | | |
| | 3 Pulse / PEI 10 | OFF | ON | OFF | | | | | | | |
| | 4 Pulse / PEI 10 | OFF | ON | ON | | | | | | | |
| | 5 Pulse / PEI 10 | ON | OFF | OFF | | | | | | | |
| | 10 Pulse / PEI 10 | ON | OFF | ON | | | | | | | |
| | 20 Pulse / PEI 10 | ON | ON | OFF | | | | | | | |
| | 100 Pulse / PEI 10 | ON | ON | ON | | | | | | | |
| | Fast Output Pulse | Lo=50ms Hi=100ms | | | ON | | | | | | |
| ★ | Slow Output Pulse | Lo=50ms Hi=300ms | | | OFF | | | | | | |
| | Inhibit level Active Low | | | | ON | | | | | | |
| ★ | Inhibit level Active High | | | | OFF | | | | | | |
| ★ | Accept PEI 10 | | | | | | ON | | | | |
| | Reject PEI 10 | | | | | | OFF | | | | |
| ★ | Accept PEI 20 | | | | | | | ON | | | |
| | Reject PEI 20 | | | | | | | OFF | | | |
| ★ | Accept PEI 50 | | | | | | | | ON | | |
| | Reject PEI 50 | | | | | | | | OFF | | |
| ★ | Accept PEI 100 | | | | | | | | | ON | |
| | Reject PEI 100 | | | | | | | | | OFF | |
| ★ | Accept PEI 200 | | | | | | | | | | ON |
| | Reject PEI 200 | | | | | | | | | | OFF |

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch.

DIP SW SETTING : 2

| FUNCTION | | SW1 | SW2 | SW3 | SW4 |
|----------|------------------------|-----|-----|-----|-----|
| ★ | Pulse Normal High (NO) | ON | | | |
| | Pulse Normal Low (NC) | OFF | | | |
| ★ | Pulse Protocol | | ON | | |
| | RS232 Protocol | | OFF | | |
| | Straight | | | ON | |
| ★ | Turn Over | | | OFF | |
| | Reserved | | | | ON |
| ★ | Reserved | | | | OFF |

★ Default setting

Note: Please reset the bill acceptor after any changes on Dip switch